DD5 & DD8 ENGINE COVERAGE PACKAGES



EW1	Air Inlet Manifold Air Intake Throttle Valve Alternator Bracket* Belt Tensioner Camshaft Assembly (including seals) Cold Pipe Assembly Connecting Rod, Bearings & Bolts Cooler Inlet Pipe Crankcase Breather Oil Separator Crankshaft Thrust Washer Cylinder Block Cylinder Head Assembly Cylinder Head Gasket	Cylinder Liner EGR System Engine-Mounted Sensors Exhaust Manifold & Bellows Fan Support Assembly Flywheel, Housing & Gasket Fuel Filter Housing Gear Case Gear Train Gear Train/Timing Case Gasket High Pressure Fuel System & Lines Integrated Engine Brake Low Pressure Fuel Pump	Main Bearing Bolts Main Bearings MCM/CPC Oil Cooler, Housing & Gaskets Oil Pan & Seals Oil Press REG & Relief Valves Oil Pump Pistons (rings, pins, retainers) Rocker Arm Assembly Rocker Cover & Seals Thermostat Housing & Gasket Turbo Compound Device & Coupling Turbocharger Outlet Elbow	Valves (exhaust, intake) Valve Springs, Guides, Inserts Vibration Damper Water Pump (excludes water pump seal)
EW2	EVERYTHING IN EW1, PLUS:	Air Compressor Fuel Injectors	Turbocharger Water Pump Seal	
EW4	EVERYTHING IN EW2, PLUS:	Aftertreatment Control Module Aftertreatment Nox Sensors Aftertreatment Pressure Sensors Aftertreatment System Mounting Aftertreatment Temperature Sensors Brackets & Clamps	DEF Pump/Metering Unit/Injection Unit Diesel Oxidation Catalyst & Housing Diesel Particulate Filter & Housing Electrical Harness & Connectors** Hydrocarbon Fuel Line Hydrocarbon Injection Valve	Hydrocarbon Metering Unit SCR Catalyst & Housing Seals – Front & Rear Crankshaft

^{*} If supplied by Detroit.



^{**}Engine harnesses and connectors installed at the Detroit plant only. Harnesses and connectors not installed at the Detroit plant can be covered under separate chassis coverage available for purchase.

Note: Component line is not inclusive. This list in intended as an overview only and specification are subject to change without notice.