



EXTENDED OPTIMUM™ USED TRUCK COVERAGE

QUICK REFERENCE GUIDE

Extended OPTIMUM is our new OEM-backed coverage option for used trucks with an expired warranty. Plan terms include 1 year/125,000 miles or 2 years/250,000 miles.

WHY IS IT VALUABLE?

Historically, customers with expired warranties or no extended coverage had to resort to less reliable, third-party warranty providers or simply go without coverage. With Extended OPTIMUM, customers can enjoy DTNA service coverage comparable to their truck's original base warranty. Repairs are completed by the Freightliner®, Western Star® or Detroit® service network using the same process and systems for all Extended Service Coverage products. Unlike third-party warranty providers, Extended OPTIMUM has no dollar caps, no deductibles, and no aggregate limits.

- ✓ **Avoid Claims Surprises:** OEM-backed means important engine and chassis parts are covered, and claims get paid without any runaround.
- ✓ **Improved Uptime:** No waiting on time-consuming repair authorizations or approvals. The customer's repair work is manufacturer pre-approved.

WHAT ARE THE PACKAGES?

Detroit® Engine Packages

For DD13®, DD15® and DD16® engines only. The engine must be in its original chassis and must match the vocation on the original vehicle product registration. *For a more comprehensive list of covered components for the engine packages, please reference the Terms of Coverage on the DTNA Portal.*



OPTIMUM Basic Detroit Engine

Air compressor, Camshaft assembly, Connecting rod bearings & bolts, Cylinder block & head assembly, ECM, Engine-mounted sensors, Exhaust manifold & bellows, Flywheel housing, Fuel injectors, Gear train, High-pressure fuel system & lines, Integrated engine brake, Low-pressure fuel pump, Main bearings & bolts, Oil cooler housing, Oil pan, Oil pump, Pistons (rings, pins, retainers), Rocker cover & arm assembly, Turbocharger, Turbo compound device & coupling, Valves (exhaust, intake), Valve springs, guides, & inserts, Vibration damper, Water pump



OPTIMUM Enhanced Detroit Engine – *Everything in OPTIMUM Basic Engine plus:*

Aftertreatment pressure sensors, Aftertreatment temperature sensors, Aftertreatment control module, DEF pump / metering unit / injection unit, Electrical harness & connectors*, Hydrocarbon fuel line, Hydrocarbon injection valve, Hydrocarbon metering unit

**if supplied by Detroit*



OPTIMUM Ultimate Detroit Engine – *Everything in OPTIMUM Basic and OPTIMUM Enhanced plus:*

Aftertreatment system mounting brackets & clamps, Diesel oxidation catalyst & housing, Diesel particulate filter & housing, SCR catalyst & housing

Freightliner and Western Star Chassis Packages



OPTIMUM Basic Chassis

Air Intake System, Charge Air Cooler, Charging System, Climate Control, Cooling System, Cranking System, Drive Shafts, Front Suspension, Rear Suspension

For a more comprehensive list of covered components for the chassis package, please reference the Terms of Coverage on the DTNA Portal.



EXTENDED OPTIMUM™ USED TRUCK COVERAGE

QUICK REFERENCE GUIDE

Extended OPTIMUM is our new OEM-backed coverage option for used trucks with an expired warranty. Plan terms include 1 year/125,000 miles or 2 years/250,000 miles.



OPTIMUM Bundle – Bundle includes OPTIMUM Ultimate Engine, OPTIMUM Basic Chassis, OPTIMUM Chassis ATS/DEF

Chassis Components

Air Intake System, Chassis ATS/DEF, Charge Air Cooler, Charging System, Climate Control, Cooling System, Cranking System, Drive Shafts, Front Suspension, Rear Suspension

Detroit Engine Components

Aftertreatment control module, Aftertreatment pressure sensors, Aftertreatment system mounting brackets & clamps, Aftertreatment temperature sensors, Air compressor, Camshaft assembly, Connecting rod bearings & bolts, Cylinder block & head assembly, DEF pump / metering unit / injection unit, Diesel oxidation catalyst & housing, Diesel particulate filter & housing, ECM, EGR system, Electrical harness & connectors*, Engine-mounted sensors, Exhaust manifold & bellows, Flywheel housing, Fuel injectors, Gear train, High-pressure fuel system & lines, Integrated engine brake, Low-pressure fuel pump, Main bearings & bolts, Oil cooler housing, Oil pan, Oil pump, Pistons (rings, pins, retainers), Rocker cover & arm assembly, SCR catalyst & housing, Turbocharger, Turbo compound device & coupling, Valves (exhaust, intake), Valve springs, guides, & inserts, Vibration damper, Water pump

**If supplied by Detroit. For a more comprehensive list of covered components for the bundle package, please reference the Terms of Coverage on the DTNA Portal.*

STANDALONE COVERAGES



OPTIMUM DT12 Transmission + Detroit Front/Rear Axles

Transmission components supplied by Detroit. Includes Detroit front-steer and rear-drive axle differential assemblies and all internally lubricated parts, axle shafts, and axle housings. Detroit front axle beam, spindles, kingpins, and kingpin bearings.



OPTIMUM Chassis ATS/DEF

DEF tank, DEF lines, Header tank



OPTIMUM Towing

Includes roadside assistance or towing (to the nearest authorized repair location) for a repair in a vehicle-down situation that prevents the safe and lawful operation of the vehicle. \$750 cap.

For a more comprehensive list of covered components for the standalone coverages, please reference the Terms of Coverage on the DTNA Portal.

HOW DO TRUCKS QUALIFY?

- **ENGINE COVERAGE:** For DD13®, DD15® and DD16® engines only. The engine must be in its original chassis and must match the vocation on the original vehicle product registration.
- **TRUCK CHASSIS COVERAGE:** Freightliner and Western Star truck chassis eligible only. Excludes Extreme Duty (logging, refuse, oil, and mining).
- **ALL COVERAGES:** Unit does not have active base warranty or extended coverage. Coverage must be purchased at a Freightliner or Western Star dealer. An Inspect and Repair form is required for all Extended OPTIMUM purchases and is valid for 30 days from inspection and/or repair date.
- Extended OPTIMUM coverage expires based on the time/duration purchased or once the vehicle reaches 7 years or 750,000 miles/1,207,500 km, whichever occurs first. Coverage begins on the contract purchase date. Mileage purchased is in addition to current odometer reading.

Need more information? Contact your ASP Regional Sales Manager at ASPHelp@DaimlerTruck.com or visit us on the DTNA Portal.